YOU HAVE MADE A WISE SELECTION...

in choosing a Da-Lite projection screen designed and engineered to produce the sharpest, most pleasing pictures with maximum convenience.

PROTECT YOUR SCREEN by keeping it rolled in its protective case when not in use. Always examine both front and back of surface before re-rolling into case to make certain screen is free of dust, dirt or other foreign matter. Use a very soft duster brush gently to remove foreign particles.

INSTALLATION


Care in mounting and care in correct operation will mean a long and satisfactory life for your Da-Lite wall/ceiling screen. Locate the screen where the audience can best see it and where other furnishings in the room permit. Mount the screen so that bottom of picture surface, when fully extended, will be above heads of viewers.

BUILT-IN HANGERS

Da-Lite wall/ceiling screens may be mounted on wall, map rails, suspended from ceiling or extension brackets. Wall screens must be mounted level and with the case-back parallel to the wall.


FOR WALL MOUNTING -

Use the keyhole slot at the back of the hanging bracket for flush wall suspension. Position screws or other fasteners into wall and hang screen by using slots.



FOR MAP RAIL MOUNTING -

Use keyhole slots in flat brackets. Do not use "D" rings.



FOR CEILING SUSPENSION

If the screen is to be ceiling mounted, two screw hooks placed in a beam or other solid surface will do the job. For dropped ceilings, Da-Lite's T-Bar Scissors Clip may be purchased.

NOTE: Whichever method is used, the screen should be free to swing forward and back and not be anchored rigidly. Mount the screen so that bottom of picture surface, when fully extended, will be above heads of viewers.

OPERATING INSTRUCTIONS

TO LOWER PICTURE SURFACE

Pull screen down all the way. HESITATE – then allow screen to retract VERY SLOWLY until it locks in place.


TO RAISE PICTURE SURFACE

Pull down on the pull bail, then raise quickly, as a window shade. Keep control of the picture surface. Do not allow it to roll uncontrolled into the case or damage is sure to result.

SCREEN ACCESSORIES

WALL BRACKETS

Da-Lite No. 6 and No. 11 Non-adjustable wall brackets and No. 23 adjustable extension wall brackets are ideal for keystone elimination, chalkboard clearance, or corner mounting. The screen brackets should be fastened to the studding or other solid surface and not in the plaster only. Suspend screen from "D" rings.



No. 23 ADJUSTABLE WALL BRACKETS Screen can be extend

Screen can be extended 18¹/₄", 20" or 24" from wall by wing nut and bolt adjustment.



No. 11 WALL BRACKETS


Screen can be extended 10" or 14" from wall by changing position of bracket.



No. 6 WALL BRACKETS


Screen can be extended 6" from wall.





TILT LOCK For Keystone Elimination

Holds back bottom of screen in tilted position to eliminate keystoning.



QUALITY FEATURES FOR BETTER PICTURES, EASIER OPERATION, LONGER LIFE

- Exclusive Camlok Roller System
- Attractively styled
- Easily installed
- Economically priced
- Completely self-storing
- Ideal for churches, schools, family centers and industrial training rooms.


For the finest in slide, film, and video projection

DA-LITE IS MORE THAN PROJECTION SCREENS


Da-Lite Tripod, Wall & Ceiling and Electric Screens

Da-Lite Overhead and Opaque Projectors





Da-Lite Model 5000 Portable



Da-Lite Lecterns Communications Cabinets



46420 Rev. 12/97

DA-LITE

WALL/CEILING PROJECTION SCREENS



OPERATING INSTRUCTIONS
FOR

MODEL B® CLASS-RITE®

DA-LITE SCREEN COMPANY, INC.

3100 North Detroit Street Post Office Box 137 Warsaw, IN 46581-0137 Phone: 219/267-8101 800-622-3737 Fax: 219/267-7804

http://www.da-lite.come-mail: info@da-lite.com